



## 990-9022 ANTI SKID ADDITIVE

### PRODUCT DESCRIPTION

990 Anti Skid Additive is designed for use in a wide range of 2-pack topcoats and floor applications.

### PRODUCT

Anti Skid Additive

990-9022

3kg

### PREPARATION OF SUBSTRATES

All substrates should be prepared in accordance with CPC technical data sheets, preparation will vary depending on substrates and products used.

### APPLICATION

To achieve an even application throughout, apply the Anti Skid additive in the process of applying the first coat of primer or topcoat. This can be achieved by applying an even wet coat on the substrate and while still wet sprinkle an even coat of 990 Anti Skid Additive over the entire surface, large areas such as floors will need to be applied in sections as you will not be able to walk over once applied. Once dry enough blow off any excess Anti Skid Additive, apply another full coat of paint to thoroughly cover the surface then allow to fully cure, (curing times will depend on coatings used) refer to the appropriate CPC technical data sheet for drying times.

For floor applications allow to dry overnight, thoroughly sweep any excess Anti Skid Additive then apply another full coat of topcoat to achieve a sealed surface, then allow to fully cure.

Anti Skid Additive can be used around work benches, stairs and anywhere a Anti Skid surface is required.

### HEALTH AND SAFETY

**Please refer to Safety Data Sheets (SDS) for full Health and Safety details, as well as product can labels.**

This product is for professional use only.  
The information given in this sheet is for guidance only. Any person using the product without first making further inquiries as to the suitability of the product for the intended purpose does so at his or her own risk and we can accept no liability for the performance of the product or for any loss or damage (other than death or personal injury resulting from our negligence) arising out of such use. The information contained in this sheet is liable to modification from time to time in the light of experience and our policy of continuous product development.  
Drying times quoted are average times at 25°C/77°F. Film thickness, humidity and shop temperature can all affect drying times.

**PPG Industries Australia Pty Ltd, 14 McNaughton Rd  
Clayton, VIC 3168 Australia**

**EMERGENCY RESPONSE NUMBER, Australia: 1800 883 254**

**PPG Industries New Zealand Pty Ltd, 5 Vestey Dr, Mt Wellington  
Auckland, New Zealand**

**EMERGENCY RESPONSE NUMBER, New Zealand: 0800 000 096**

PPG Logo is a registered trademark of PPG Industries Ohio, Inc.

Protec is a registered trademark of Protec Pty Ltd.

Startline is a registered trademark of PPG Industries Australia Pty Ltd.